

LV-360 PARTS KIT

Item	Description	Part No.	Item	Description	Part No.
1	Body	301001	24	Firing Pin Assembly	301400
2	Pin, Trigger	301034	25	Spring Holder	301420
3	Holder, Advance Bar	301529	26	Spring	301421
4	Advance Bar	301530	27	Nut	301422
5	Spring, Advance Bar	301531	28	Spring, Sear Holder	301026
6	Trigger	301533	29	Spring, Firing Pin	301025
7	Bolt	301015	30	Plug	301028
8	Liner	301100	31	Rubber Pad Assy.	301600
9	Annular Spring	301014	32	Rock Arm	301844
10	Ball	301013	33	Spring	301840
11	Stop	301012	34	Spring	301843
12	Push Pin	301016	35	Pin, Rock Arm	301845
13	Ball	301046	36	Bushing	301532
14	Spring	301047			
15	Piston Sleeve	301006			
16	Piston Flat	301200			
17	Piston Ring	301208			
18	Guide	301010			
19	Baseplate	301009			
20	Shear Clip	301011			
21	Sear Holder	301300			
22	Sear	301023			
23	Spring, Sear	301024			

